


🌟 Fibre Optic Backdrop – Easy Setup Guide (Dry Hire)

Provided by Loch Lomond Balloons

Proudly hiring to customers across Greater Glasgow & surrounding areas



Thanks for hiring with **Loch Lomond Balloons**! Please follow the steps below to keep your fibre optic backdrop looking stunning and to ensure a smooth return 🌟

📦 What You'll Receive

- Fibre optic backdrop curtain
- Light box (this makes the fibres glow)
- Power cable
- Remote or control dial (if included)
- Carry bag

👉 Please check all items on collection. Let **Loch Lomond Balloons** know immediately if anything is missing or damaged.

🔧 How to Set It Up

1. Choose the Right Spot

- **Indoor or fully undercover use only**
- Close to a standard power socket
- Enough space to safely place the **light box** behind or beside the curtain

2. Hang the Backdrop

You can hang the curtain from:

- Pipe & drape stand
- Curtain pole
- Venue-approved hooks or ties

Important:

- Hold the backdrop by the **top fabric only**
- Allow the fibre strands to fall naturally
- **Do not pull, bend, knot, or twist the fibres**

3. Switch the Lights On

1. Place the light box on a flat, dry surface
2. Do not cover the light box — it needs airflow
3. Plug the fibre cable into the light box
4. Plug into the power socket and switch on
5. Use the remote or dial to select your colour or setting

🌟 Tip: A steady glow or slow colour change works best for events and photos

🌟 Styling Tips

- Looks best in **low-light settings**
- Gently spread the fibres for fuller coverage
- Ideal for head tables, backdrops & photo areas

⚠️ Safety & Care

- Keep all equipment **dry at all times**
- Do not sharply bend or pull fibres
- Keep away from heat, candles & open flames
- Not suitable for children to play with
- Do not look directly into the light box

📦 Pack-Down (Please Read)

1. Turn off and unplug from the power
2. Allow the light box to cool
3. Gently disconnect the fibre cable
4. Starting at the top, carefully gather fibres downward

5. Lay fibres straight — **do not coil or tightly wrap**
6. Pack everything neatly back into the carry bag

! Damage caused by pulling, snapping fibres, or poor packing may result in repair or replacement charges.

Return Condition

- Items returned **clean, dry & untangled**
- All equipment included
- Returned at the agreed time to avoid late fees

Thank you for choosing **Loch Lomond Balloons** — we love being part of your celebrations across **Greater Glasgow** ✨